

SEAT

Code	Code	Code	Code
<b>0-9</b>			
1Z ..... 104			
<b>A</b>			
AAZ ..... 104	ANU ..... 105	<b>B</b>	BNV ..... 103
AFN ..... 104-105	APP ..... 104	BAM ..... 104	BPX ..... 106
AGR ..... 104	ARL ..... 105	BBU ..... 104	BTB ..... 105
AHF ..... 105	ARY ..... 104	BJB ..... 106	BUK ..... 106
AHU ..... 104	ASV ..... 104-105	BJX ..... 104	BVK ..... 105
AJH ..... 104	ASZ ..... 105	BKC ..... 106	BXE ..... 106
AJQ ..... 104	ATD ..... 105	BKD ..... 107	BXF ..... 106
ALH ..... 104-105	AUQ ..... 104	BKV ..... 104	
AMF ..... 103	AUY ..... 105	BLS ..... 106	<b>C</b>
AMK ..... 104	AVG ..... 104	BLZ ..... 104	CAGA ..... 107
	AWC ..... 104	BMM ..... 107	CAVA ..... 103
	AXR ..... 105	BMN ..... 107	CAVE ..... 103
	AZV ..... 107	BMS ..... 103	CAVF ..... 103
		BNM ..... 104	CFMA ..... 104

SEAT

Ltr.	Code	Power	Models	Year	Part No.	Image	Part No.
1,4	AMF	55 kW (75 PS)	AROSA TDI CORDOBA TDI IBIZA TDI	01/00-12/05		04-10019-01	70-41369-00
1,4	BMS	59 kW (80 PS)	CORDOBA TDI IBIZA TDI	06/05-06/10		04-10171-01	70-41369-00
1,4	BNM BNV	51-59 kW (70-80 PS)	CORDOBA TDI IBIZA TDI	05/05-11/09		04-10118-01	70-41369-00
1,4	CAVA CAVE CAVF	110-132 kW (150-180 PS)	ALHAMBRA TSI IBIZA TSI	06/09→		04-10202-01	70-41369-00

SEAT							
Ltr.							
1,8	AJH AWC CFMA	110 kW (150 PS) ALHAMBRA T EXEO T	10/97-05/10	<b>04-10045-01</b>		<b>70-41369-00</b>	
1,8	AJQ APP ARY AUQ BBU BJX BKV BLZ	110-132 kW (150-180 PS) IBIZA T LEON T TOLEDO T	11/99-05/08	<b>04-10057-01</b>		<b>70-41369-00</b>	
1,8	AMK BAM	154-165 kW (209-225 PS) LEON T	02/02-06/06	<b>04-10198-01</b>		<b>70-41369-00</b>	
1,9	AAZ	55 kW (75 PS) CORDOBA TD IBIZA TD TOLEDO TD	↔→6K-ZR114699, 05/91-03/99 6K-ZR643999 ↔→6K-R131500, 6K-R671499 ↔→1L-ZD339500*	<b>04-10031-01</b>		<b>70-41369-00</b>	
1,9	AAZ AGR AHU IZ	55-66 kW (75-90 PS) ALHAMBRA TDI CORDOBA TD CORDOBA TDI IBIZA TD IBIZA TDI LEON TDI TOLEDO TD TOLEDO TDI	05/91-03/10	<b>04-10049-01</b>		<b>70-41369-00</b>	
1,9	AFN ALH ASV AVG	66-81 kW (90-110 PS) ALHAMBRA TDI CORDOBA TDI IBIZA TDI	08/96-12/02	<b>04-10021-01</b>		<b>70-41369-00</b>	

**(NEW)**

SEAT							
Ltr.							
1,9	AFN	81 kW (110 PS) CORDOBA TDI IBIZA TDI TOLEDO TDI	11/96-08/99	<b>04-10058-01</b>		<b>70-41369-00</b>	
1,9	AHF ALH ARL ASV ASZ AUY AXR BTB BVK	66-110 kW (90-150 PS) ALHAMBRA TDI CORDOBA TDI IBIZA TDI LEON TDI TOLEDO TDI	04/99-03/10	<b>04-10023-01</b>		<b>70-41369-00</b>	
1,9	ANU	66 kW (90 PS) ALHAMBRA TDI	04/96-03/10	<b>04-10016-01</b>		<b>70-41369-00</b>	
1,9	ATD	74 kW (100 PS) CORDOBA TDI IBIZA TDI	↔→6L-4000001→ 02/02-11/09	<b>04-10023-01</b>		<b>70-41369-00</b>	

SEAT



SEAT						
Ltr.						
1,9	BJB BKC BXE BXF	66-77 kW (90-105 PS)	ALTEA TDI LEON TDI TOLEDO TDI	04/04→	<b>04-10018-01</b>	<b>70-41369-00</b> 
1,9	BLS	77 kW (105 PS)	ALTEA TDI ALTEA TDI LEON TDI LEON TDI TOLEDO TDI TOLEDO TDI	04/04→	<b>04-10155-01</b>	<b>70-41369-00</b> 
1,9	BPX BUK	118 kW (160 PS)	IBIZA TDI	03/04-02/08	<b>04-10164-01</b>	<b>70-41369-00</b> 

**[NEW]**

SEAT						
Ltr.						
2,0	AZV BKD	100-103 kW (136-140 PS)	ALTEA TDI LEON TDI TOLEDO TDI	03/04→	<b>04-10050-01</b>	<b>70-41369-00</b> 
2,0	BMM	103 kW (140 PS)	ALTEA TDI LEON TDI TOLEDO TDI	10/05→	<b>04-10155-01</b>	<b>70-41369-00</b> 
2,0	BMN	125 kW (170 PS)	ALTEA TDI LEON TDI TOLEDO TDI	01/06→	<b>04-10172-01</b>	<b>70-41369-00</b> 
2,0	CAGA	105 kW (143 PS)	EXEO TDI	12/08→	<b>04-10131-01</b>	<b>70-41369-00</b> 

**[NEW]**

SEAT