













ISUZU

Code	Code	Code	Code
<b>0-9</b>			
4EC1T .....	47		
4FG1T .....	47		
4JB1T .....	47		
4JB1-TC .....	47		
4JX1 .....	47		

ISUZU					
Ltr.					
1,5	4EC1T	49 kW (67 PS) GEMINI TD	02/88-12/90	<b>04-10004-01</b> 	<b>70-41369-00</b> 
2,4	4FG1T	56 kW (76 PS) MIDI D MIDI TD	01/94→	<b>04-10003-01</b> 	<b>70-41369-00</b> 
2,8	4JB1T 4JB1-TC	67-85 kW (91-116 PS) TROOPER TD	10/87→	<b>04-10003-01</b> 	<b>70-41369-00</b> 
3,0	4JX1	118 kW (160 PS) TROOPER DTI	04/00→	<b>04-10119-01</b> 	<b>70-41369-00</b> 